

**NATIVE**



**Glasgow**

**Appliance Guide**

We're not all wizards when it comes to technology. Here's a few instructions to help you make the most of the appliances in your apartment.

## Microwave & Grill



### Microwave

Press button indicated by arrow.

Pressing this should display P100 on the screen, meaning the microwave is on full power. i.e 100%.

By pressing this further, you will decrease the power. Once you have your preferred power setting, press **Start**.

You can now turn the dial clockwise to reach the time you need to heat your food.

### Grill

You can do this in the microwave! Repeatedly press the button indicated by the arrow (about six times) until "G" is displayed. This indicates you are now in grill mode.

Press **Start** and turn the dial clockwise to reach the time you need to grill your food.

## The Hob


Tap the On/Off icon indicated by **arrow 1** to get started.

Choose the hob you want to use by tapping the corresponding ring indicator (**arrow 2**).

By tapping the + and - icons, you can select the heat setting required (**arrow 3**).

Make sure you turn off the hob when you've finished cooking. Do this by tapping the On/Off icon (**arrow 1**).

**The hob will display "H" when powered off.** This is to signify the hob is still hot to the touch even in off mode. This will disappear as the hob cools.




## Air Conditioning and Heating

### Heating

Feeling a little chilly? Let's get you warmed up. Turn on the unit by pressing the blue button.

Press button indicated by arrow until you see the **sunshine symbol** appear on the screen above. This should display the room temperature too. This can be turned up or down by pushing the white buttons directly underneath the blue power button.



### Air Conditioning

Bit warm? Turn on the unit by pressing the blue button to set a temperature that's perfect for you.

Press the button indicated by the arrow until the **snow flake symbol** appears. This should also display the room temperature. This can be turned up or down by pushing the white buttons directly underneath the blue power button.

## Connecting to Wi-Fi

Wi-Fi is free for all! You'll find your unique apartment password on the keycard holder you were given when you arrived.

Inside the holder you will find the wi-fi username unique to your apartment e.g. Native 123.

Open the wi-fi settings on your device and search until your apartment username appears.

Select your apartment number and enter the password written in your keycard holder.

Still need a hand to get your appliances working?

Pop down to reception or **call 0141 288 7730** and our Natives will be there to help.

**NATIVE**

[www.nativeplaces.com](http://www.nativeplaces.com)